

Оправки для закрепления торцевых фрез

MAS 403 BT

Код заказа для BT30	D	D1	L
BT30 FM16	16	40	40
BT30 FM22	22	48	40

Код заказа для BT40	D	D1	L
BT40 FM16	16	40	40
BT40 FM22	22	48	45
BT40 FM27	27	60	45
BT40 FM32	32	78	50
BT40 FM40	40	89	55

Код заказа для BT50	D	D1	L
BT50 FM16	16	40	55
BT50 FM22	22	48	55
BT50 FM27	27	60	55
BT50 FM32	32	78	55
BT50 FM40	40	89	55



Патроны для закрепления инструмента с хвостовиком WELDON

Код заказа для BT40	D1	D	L
BT40 W06	6	25	50
BT40 W08	8	28	50
BT40 W10	10	35	63
BT40 W12	12	42	63
BT40 W14	14	44	50
BT40 W16	16	48	63
BT40 W20	20	52	63
BT40 W25	25	65	90
BT40 W32	32	72	100
BT40 W40	40	80	120

Код заказа для BT50	D1	D	L
BT50 W10	10	35	63
BT50 W12	12	42	80
BT50 W16	16	48	80
BT50 W20	20	52	80
BT50 W25	25	65	100
BT50 W32	32	72	105
BT50 W40	40	80	120

